VERY IMPORTANT! UPDATE YOUR SHELL ITR+ DEVICES

UPDATE



For an optimal functioning of your **Shell Interroute plus (ITR+) OBU an IT update** is currently in progress.

To ensure that your ITR+ OBUs functions correctly in Belgium it is mandatory, that they are continuously and always connected with their power cable to the power source of the truck. The update will be submitted over the air only if the OBU is connected to the power source! If the OBU is not connected to the power source the update will fail and the OBU will not work in Belgium anymore.

Please instruct your drivers to connect the ITR+ OBU to a power source all the time when the truck is moving.

Please contact our customer service team for any further questions.

Have a good trip with Shell ITR+

Your Shell Card Team

